


IFP IP3150/IP3300/IP3500/IP3650 MODEL CODING & NOMENCLATURE




* HOW TO SPECIFY MODEL CODE



SAMPLE SINGLE PUMP MODEL CODE

1	2	3	4	5	6	7
IP	3150	A	293	FW	AB 20	65
(IP) PUMP / (IM) MOTOR	SERIES 3150/3300/3500/3650	SINGLE UNIT	SHAFT END COVER SEE Page E2.6	PORT END COVER SEE Page E2.7	GEAR HOUSING SEE Page E2.8	DRIVE SHAFT SEE Page E2.9-E2.10



SAMPLE TANDEM PUMP MODEL CODE

FIRST SECTION			ADDITIONAL SECTIONS						
1	2	3	4	5	6	7	8	9	10
IP	3500	B	498	EM	AB20	7	HP	AB17	1
(IP) PUMP / (IM) MOTOR	SERIES ... 3150/3300/3500/3650	TANDEM UNIT	SHAFT END COVER SEE Page E2.6	PORT END COVER SEE Page E2.7	FRONT GEAR HOUSING SEE Page E2.8	DRIVE SHAFT SEE Page E2.9-E2.10	BEARING CARRIER SEE Page E2.12-E2.13	BACK GEAR HOUSING SEE Page E2.8	CONNECTING SHAFT SEE Page E2.11