


# IFP IP3100/IP5100/IP7600 MODEL CODING & NOMENCLATURE




## \* HOW TO SPECIFY MODEL CODE



### SAMPLE SINGLE PUMP MODEL CODE

1	2	3	4	5	6	7
IP	3100	A	642	BE	YL 20	25
(IP) PUMP / (IM) MOTOR	SERIES ... 3100/5100/7600	SINGLE UNIT	SHAFT END COVER SEE Page E1.7-E1.8	PORT END COVER SEE Page E1.9	GEAR HOUSING SEE Page E1.10 - E1.11	DRIVE SHAFT SEE Page E1.11-E1.14



### SAMPLE TANDEM PUMP MODEL CODE

FIRST SECTION						ADDITIONAL SECTIONS			
1	2	3	4	5	6	7	8	9	10
IP	5100	B	578	BY	OL20	11	C	OL17	1
(IP) PUMP / (IM) MOTOR	SERIES ... 3100/5100/7600	TANDEM UNIT	SHAFT END COVER SEE Page E1.7-E1.8	PORT END COVER SEE Page E1.9	FRONT GEAR HOUSING SEE E1.10 - E1.11	DRIVE SHAFT SEE Page E1.10 - E1.11	BEARING CARRIER SEE Page E1.15	BACK GEAR HOUSING SEE Page E1.10 - E1.14	CONNECTING SHAFT SEE Page E1.14